



GS Series Generator Sets

GS26-32DE Series Diesel Generator Sets

For genset specifications and data, refer to the specific genset technical data sheet.

When ordering, please quote genset part number. See page 4 for part number extension information.

Standard Equipment: Includes a radiator-cooled diesel engine with pusher fan, integral base frame, vibration isolators, battery cables and hold-down, 12-volt electric starter motor and belt-driven battery charging alternator; fuel control solenoid-energized to run, heavy-duty air cleaner, fan and belt guard, mechanical fuel lift pump, close coupled Mecc Alte 12-lead AVR controlled alternator and the DA control panel.

Standard 'DA' Control Panel: This control comes complete as a manual or auto start control with hour meter mounted in the generator box for the GS32 and in a vibration isolated cabinet for the GS26. When in "Auto" position a simple switch closure of any kind will signal the set to start. Controls provide safety shutdown protection, with LED indication for low oil pressure, high temperature, over/under speed and fail to start after three attempts. Low battery voltage will have a warning. It comes standard with two configurable input/outputs.

Standard generator ratings with Mecc Alte alternator

Model Number	Engine Model	EPA Compliant	HZ	KW Rating 1 Phase	KW Rating 3 Phase	List Price
GS26DE-LM-DA	DWS4	Yes	60	22.5 KW 22.5 KVA ST/BY	26.4 KW 33 KVA ST/BY	\$12,584
GS32DE-LM-DA	DWS4	Yes	60	30.1 KW 30.1 KVA ST/BY	32.1 KW 40.1 KVA ST/BY	\$13,485

U.S. Dollar List Prices, Ex-works; Olathe, Kansas USA

All ratings are calculated at sea level, 77° F and 10% humidity. See data sheet for derate factors.

For prime power ratings divide by 1.1.

Prices are not valid for accessories shipped loose or field installation kits. Please add 10% for loose accessories (Not installed on set) or ordered without genset purchase.

See page 3 for optional Newage Alternator pricing & ratings.

See the following pages for additional accessories and optional equipment.

Please consult Lister Petter Americas for accessories or option not listed.

Prices and Specifications are subject to amendment without notice. All orders are subject to the Company's Terms and Conditions of Sale.

Lister Petter Americas Inc. • 815 E. 56 Highway • Olathe, Kansas 66061-4914 USA • Telephone: (913) 764-3512 • Fax: (913) 764-5493

www.lister-petter.com



LISTER PETTER GS SERIES ACCESSORIES

GS26-32D

December 2006

Page 2

ACCESSORY GROUP	DESCRIPTION	LIST PRICE	
		GS26	GS32
Battery Charger	Fully automatic battery charger, 6 amp 12 VDC, 120 V, 60 Hz with LED indication.	\$106	
Circuit Breakers	Circuit breakers (All voltages but 480/600 volt.) Sized for your genset	\$240	\$470
	Circuit breakers 480 & 600 volt Sized for your genset	\$240	\$240
Control Panel Options	DB Control Upgrade (See page 4 for details.)	465.00	\$465.00
	Low coolant level shutdown	\$185	
	Panel mounted emergency stop switch	\$53	
	Low fuel level alarm (For use with DW tanks)	\$125	
	Basin rupture alarm (For use with DW tanks)	\$135	
Enclosures	Basic weather resistant enclosure - Powder coated steel	\$1,055	
	Powder coated aluminium	\$1,507	
	Sound attenuated weather enclosure (Sound baffles shipped loose)		
	Powder coated steel	\$1,595	
	Powder coated aluminium	\$2,047	
Exhaust Equipment	Weld on flange	\$86	
	Threaded flange 1 1/2"	\$220	
	Industrial silencer	\$192	
	Critical silencer	Not available at this time.	
	Flex pipe	Not available at this time.	
Governing	12-Volt electronic governor, factory installed	Not available at this time.	
Heaters	Coolant heater - tank type 120 volt	\$181	
	Coolant heater - tank type 240 volt	\$181	
	120 Volt anti-condensation heater	\$310	
	240 Volt ant-condensation heater	\$310	
Lubrication	Mechanical oil pressure guage	\$47	
Transfer Switches	100 Amp 2 pole Transfer switch	\$1,145	
	150 Amp 2 pole Transfer switch	\$1,305	
	100 Amp 3 pole Transfer switch	\$1,305	
	Additional sizes available.	Consult LPAI	

Prices and Specifications are subject to amendment without notice. All orders are subject to the Company's Terms and Conditions of Sale.

Lister Petter Americas Inc. • 815 E. 56 Highway • Olathe, Kansas 66061-4914 USA • Telephone: (913) 764-3512 • Fax: (913) 764-5493

www.lister-petter.com



LISTER PETTER GS SERIES ACCESSORIES

GS26-32D

December 2006

Page 3

ACCESSORY GROUP	DESCRIPTION	LIST PRICE	
		GS26	GS32
Fuel Tank Options	Single wall 50 gallon fuel tank <i>(Steel sub-base.)</i>	\$1,695	
	Double wall 70 gallon fuel tank UL 142	\$1,999	
	Double wall 130 gallon fuel tank UL 142 <i>(furnished loose)</i>	\$3,100	
	Double wall 200 gallon fuel tank UL 142 <i>(furnished loose)</i>	\$4,295	
Literature	Generators operators manual	TBA	
	Generators parts manual	TBA	
	Engine parts manual	\$37	
	Engine operation manual	\$15	
	Installation kit/manual	TBA	
Shipping	Open wooden crate	\$170	
	Export wooden crate	\$335	
Alternator End Options	Newage 12 wire 17 winding. <i>(Must be used for 600 volt option.)</i>	\$610	\$340
	Newage 12 wire reconnectable - Three Phase Only (311 winding)		

Generator set ratings with the optional Newage alternator

Genset	HZ	Winding	KW Rating 1 Phase	Winding	KW Rating 1 Phase	KW Rating 3 Phase
GS27D	60	06	27.5 KW 27.5 KVA ST/BY	311	21.5 KW 21.5 KVA ST/BY	28 KW 35 KVA ST/BY
	50	05	20 KW 20 KVA ST/BY	311	18 KW 18 KVA ST/BY	22 KW 27.5 KVA ST/BY
GS32D	60	06	N/A	311	30 KW 30 KVA ST/BY	32.3 KW 40.4 KVA ST/BY
	50	05	N/A	311	26.7 KW 26.7 KVA ST/BY	27.1 KW 33.8 KVA ST/BY


For any additional accessories you may require that aren't listed here please call for special quote or advice.



Optional "DB" Control Panel Details

Optional 'DB' Control Panel: This control comes complete as a manual or auto start control mounted in the generator box for the GS32 and in a vibration isolated cabinet for the GS26. When in "Auto" position a simple switch closure of any kind will signal the set to start. The controls provide safety shutdown protection for low oil pressure, high temperature, over/under speed and a over crank fault after three failed attempts to start. Using a push button you can easily scroll through the LCD showing the generator sets A/C voltage, amperage and frequency. The engine will be monitored for oil pressure, temperature, D/C battery volts, and engine hours run. It comes standard with five fully configurable inputs and three configurable outputs for either warnings or shutdowns.

Model Number Breakout and Definition



Prices and Specifications are subject to amendment without notice. All orders are subject to the Company's Terms and Conditions of Sale.

Lister Petter Americas Inc. • 815 E. 56 Highway • Olathe, Kansas 66061-4914 USA • Telephone: (913) 764-3512 • Fax: (913) 764-5493

www.lister-petter.com